




# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model 345AB---171C or 287C  
PAC-MAN  
MIDWAY



1. Insert 345B program card into "B" connector on TF-650, number side up.
2. Insert 345A program card into "A" connector on TF-650, number side up.
3. Insert 171C or 287C into 25-pin connector on the TF-650, number side up.
4. Insert GAME BOARD into 171C or 287C card connector.
5. Slide POWER switch to ON.
6. Push COIN switch for credit.
7. START 1 is 1 PLAYER.  
START 2 is 2 PLAYER.
8. SR1 is MAN LEFT  
SR3 is MAN RIGHT  
SR2 is MAN UP  
SR4 is MAN DOWN
9. TEST switch is on 345A card.
10. SR6 is RESET.

*For cocktail 2<sup>nd</sup> player  
ground IC 8H pin 4*

*test for steering ground IC 8F pin 2 Down  
6 right  
4 left  
10 up*