



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model 266A,C

ROBOT BOWL, CIRCUS

Exidy




1. Insert the 266A card into the program "A" connector, number side up.
2. Insert the 266C card into the test fixture, number side up.
3. Insert the game board into the 266C card.
4. Connect an ungrounded speaker to the speaker leads.
5. Slide the 5 VOLT switch to ON.
6. Slide the POWER switch to ON.
7. Coin the game by pressing COIN.
8. Press START 1 to start game.
9. START 2 is ANT.
10.

MAN	LEFT	SL-6
MAN	RIGHT	SL-7
	ROLL	SL-5
FAST	BALL	SL-2
HOOK	LEFT	SL-1
HOOK	RIGHT	SL-3
11. The L.E.D. on the 266 A card indicates power to the relay in a 2 player game.
12. For the CIRCUS board, SL-2 is 2 Player START. LLP controls the board.

Robot Bowl

EXIDY

266



(Pulse when start Z pressed)

6502

1↓ when ball rolls

0↑ when ball rolls

50 when ball rolls

except ~~when~~ when man moneys →