



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 151 A & B

TV FLIPPER

Midway

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 151 A card into program "A" connector, number side up.
2. Insert 151 B card into program "B" connector, number side up.
3. Insert computer board into test fixture using 24 pin orientation.
4. Jumper pins 1 and 6 together on 10 pin remote connector which is connected to computer board.
5. Turn power switch on.
6. Turn 5 volt internal switch on.
7. Push coin switch once for 1 player twice for 2 player. Credit lite will light.
8. Push start 1 switch once for 1 player, twice for 2 players.
9. RRP is paddle
10. SR6 is serve ball.
11. SR5 is tilt switch.
12. LED indicators on 151 A card
 - 1 PLY is one player lite
 - 2 PLY is two players lite
 - 1 UP is first player up lite
 - 2 UP is second player up lite
 - GO is game over lite