



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 401A

TUNNEL HUNT

CENTURI

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP			RLP	SR1	SR5	SR3	RRP	ON	OFF
		x	x			START1			x	x			
x				x	x	x	x	x			x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF
												ON	OFF

1. Insert "A" card in slot "A" with the number side up.
2. Connect two short leads to speaker.
3. Connect the 22/44 pin connector to the board.
4. Turn 5V to ON position.
5. Turn POWER to ON position.
6. Controls are:
 - COIN-----LEFT COIN
 - SR6-----RIGHT COIN
 - START 1--START (start LED should flash when there is credit, it should stay lit when pushed.)
 - RRP-----CONTROL KNOB----LEFT/RIGHT
 - RLP-----CONTROL KNOB----UP/DOWN
 - SR1-----SHIELD
 - SR3-----FIRE BUTTON
 - AUDIO 1 & 2 switch is on card
 - Test switch is on card.

The 5V switch may have to be turned off and on a couple of times to get the proper game operation.

ROM SIGNATURES

CPU BOARD

LOCATION

TYPE

SIGNATURE

PERSONALITY BOARD

A8	82S131	not available	B16
B8	"	" "	
C11	82S123	5943	82S123/D16
D11	"	4833	"
C10	82S137	FHF7	82S137/A18
H9	"	H8U3	"
N4	82S129	H860	82S129/A16
D1	TMS2516JL-45	97H3	2716/I24
E/F1	MM2716Q	H2P5	"
F/H1	"	7CA5	"
J1	MB81516	72F0	"
K1	TMS2516JL-45	2F7A	"
L/M1	"	4352	"