



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions

For Model

107 B, 107 C

TV PING PONG

CD I

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 107 B card into program "B" connector with number side up.
2. Insert 107 C adapter card into test fixture.
3. Insert computer board into 107 C adapter card.
4. Push coin switch to start game.
5. LLP is left paddle.
RRP is right paddle.