



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246 • 2271 Arbor Blvd.  
 Dayton, Ohio 45439  
 Telephone (513) 299-0990


# Operating Instructions

For Model

366A

CRAZY CLIMBER

NICHIBUTSU



1. Insert 366A program card into "A" connector on TF-650 with number side up.
2. Insert GAME BOARD into 44-pin cable connector with RED DOT UP.
3. Connect 6-pin cable connector to GAME BOARD header pins with slots facing away from board.
4. Connect speaker across RED and BLACK 6-inch pigtail leads on 44-pin connector.
5. Slide 5-VOLT switch to ON.
6. Slide POWER switch to ON.
7. Controls are:

COIN is CREDIT  
 START 1 is 1 PLAYER  
 START 2 is 2 PLAYER  
 SELECT 1 or 2 PLAYER SWITCH GROUP ON 366A card.  
 SR1 is 1 PR LEFT  
 SR2 is 1 PR DOWN  
 SR3 is 1 PR RIGHT  
 SR4 is 1 PR UP  
 SL1 is 1 PL LEFT  
 SL2 is 1 PL DOWN  
 SL3 is 1 PL RIGHT  
 SL4 is 1 PL UP

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>
A6	C1	AOP3	HN462716	2716/124
B6	C2	7A8P	HN462716	2716/124
H6	C3	1546	HN462716	2716/124
J/K6	C4	1F3U	MB8516	2716/124
L/M6	C5	6966	HN462716	2716/124
N6	C6	20A4	MB8516	2716/124
4C	CC7	PF60	TMS2532	TMS2532/L24M
4E	CC8	8048	TMS2532	TMS2532/L24M
4F	CC9	77P6	TMS2532	TMS2532/L24M
4J	CC10	80A9	TMS2532	TMS2532/L24M
4L	CC11	6P05	TMS2532	TMS2532/L24M
4P	CC12	UF11	TMS2532	TMS2532/L24M
4R	CC13	87AP	TMS2532	

Alternate Group

C4	CC7A	H871	HN462532	TMS2532/L24M
E4	CC8A	695A	HN462532	TMS2532/L24M
F4	CC9	77P6	HN462532	TMS2532/L24M
J4	CC10	80A9	HN462532	TMS2532/L24M
L/K4	CC11	6P05	HN462532	TMS2532/L24M
P/N4	CC12A	A140	HN462532	TMS2532/L24M
R4	CC13A	902U	HN462532	TMS2532/L24M