




Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990

Operating Instructions

For Model 354A
THE END
STERN



1. Insert 354A program card into "A" connector on TF-650, number side up.
2. Connect 18/36 pin edge-connector to GAME BOARD with RED DOT UP.
3. Connect speaker across two short leads on 18/36 pin edge-connector.
4. Slide 5 VOLT switch to ON.
5. Slide POWER switch to ON.
6. COIN 1 switch is COIN
 COIN 2 switch is SL7
 START 1 is 1 PLAYER
 START 2 is 2 PLAYER
 1st PLAYER LEFT is SR1 2nd PLAYER LEFT is SL1
 1st PLAYER RIGHT is SR3 2nd PLAYER RIGHT is SL3
 1st PLAYER FIRE is SR5 2nd PLAYER FIRE is SL5
7. TEST switch is SL6.

ROM SIGNATURES

| <u>LOCATION</u> | <u>TYPE</u> | <u>SIGNATURE</u> | <u>PERSONALITY BOARD</u> |
|-----------------|-------------|------------------|--------------------------|
| IC-13 | TMS-2516 | 8834 | 2716 (124) |
| IC-14 | TMS-2516 | 1A78 | 2716 (124) |
| IC-15 | TMS-2516 | 01U2 | 2716 (124) |
| IC-16 | TMS-2516 | H667 | 2716 (124) |
| IC-17 | TMS-2516 | U30C | 2716 (124) |
| IC-18 | TMS-2516 | F8PH | 2716 (124) |
| IC-55 | TMS-2516 | 39F7 | 2716 (124) |
| IC-56 | TMS-2516 | CF37 | 2716 (124) |
| IC-30 | TMS-2516 | 2802 | 2716 (124) |
| IC-31 | TMS-2516 | 0A1P | 2716 (124) |
| IC-86 | MMI6331-1 | F5A6 | D16 |