




Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 390A
DIG DUG
ATARI



1. Insert 390A program card into "A" connector of TF-650, number side up.
2. Connect 22-pin ribbon cable connector to game board with RED DOT in #1 position.
3. Connect speaker to two (2) short lead on the 390A program card.
4. Slide 5V switch to ON.
5. Slide POWER switch to ON.
6. CONTROLS ARE:

COIN-----COIN LEFT
 SR6-----COIN RIGHT
 START 1 is 1 PLAYER START
 START 2 is 2 PLAYER START
 SR1-----LEFT
 SR2-----UP
 SR3-----RIGHT
 SR4-----DOWN
 SR5-----PUMP BUTTON

LEDS ON CARD SHOULD FLASH ONCE WHEN COIN LEFT OR COIN RIGHT IS PUSHED.

LED NEXT TO START 1 WILL FLASH WHEN ONE OR MORE CREDITS ENTERED.

LED NEXT TO START 2 WILL FLASH WHEN TWO OR MORE CREDITS ARE ENTERED.

ROM SIGNATURES

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
5L	AM2732DC	4A52	2732/M24
6C	"	212F	"
6D	"	47H8	"
6L	"	UPCU	"
6M	TMM2732D1	A94U	"
6N/P	AM2732DC	73H5	"
6R	"	4CA0	"
7A/B	TMS2532JL-45	7F75	TMS2532/L24M
7C	HN462532G	F7P6	"
8A/B	TMS2532JL-45	80H3	"
8C	"	F523	"
8R	AM2716DC	UC63	2716/I24
9N	D2732A	3C9A	2732/M24
10C/D	TMS2532JL-45	7064	TMS2532/L24M