




Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990

Operating Instructions

For Model 388 A
ZAXXON
SEGA/GREMLIN



1. Insert 388 A program card into "A" connector of TF-650 with number side up.
2. Connect 22 pin ribbon cable connector to game board with red dot up.
3. Connect speaker across two short leads on 22 pin ribbon cable connector.
4. Slide 5V switch to on.
5. Slide power switch to on.
6. Controls are:

COIN-COIN A

SR6 - COIN B

START 1 is 1 PLAYER START

START 2 is 2 PLAYER START

SR1 is Left

SR2 is Up

SR3 is Right

SR4 is Down

SR5 is Fire

SL6 is Reset

SL7 is Service Switch

7. Led next to start 1 should flash when coin or SR6 is pushed.
8. Led next to start 2 should light up when fire button is pushed.