



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 114 A, B

AZTEC HOCKEY

PMC

		SL2			START 2			SR2			5V		
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP	START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF	
x	x	x	x	x	x	x	x	x	x	x			
		SL4						SR4					
		x						x					
	SL6		SL7		COIN		SR6		SR7		POWER		
	x		x		x		x		x	x	ON	OFF	

1. Insert 114 A card into program "A" connector, number side up.
2. Insert 114 B card into program "B" connector, number side up.
3. Insert computer board into test fixture using 22 pin orientation.
4. Push POWER switch to ON.
5. Push 5 VOLT switch to ON.
6. Push COIN switch once for 2 players, twice for 4 players.
7. Push START 1 switch once.
8. LLP is left left paddle.
 LRP is left right paddle.
 RLP is right left paddle.
 RRP is right right paddle.
9. GO is game over LED on 114 A program card.
10. START 2 is TILT switch.