



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-8161

# Operating Instructions

## For Model 276AB, 265C

DESTROYER

ATARI

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert the 276B card into the program B connector, number side up.
2. Insert the 276A card into the program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the Destroyer game board into the 265C card.
5. Connect a speaker to the speaker leads.
6. Slide the power switch to ON.
7. PRESS:
  - COIN or SR-6 to coin game
  - START to start the game
  - START--2 to reset the game
8.
  - LLP       Level Control
  - SL-5      Release
  - SL-6      Speed