



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161


Operating Instructions

For Model _____

254AB, 265C

TRIPLE HUNT

ATARI



1. Insert the 254B card into the program B connector, number side up.
2. Insert the 254A card into the program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the Triple Hunt game board into the 265C card.
5. Connect a speaker to the speaker leads.
6. Slide the POWER switch to "ON".
7. To align the gun, set the slide switch on the 254B card to "TEST".
 - A. Turn LLP and LRP counter-clockwise and press SL-5 one time.
 - B. Turn LLP and LRP clockwise and press SL-5.
 - C. The gun control circuit is now aligned. Set the slide switch on the 254B card out of the "TEST" mode.

NOTE: STEP 7 MUST BE PERFORMED EVERY TIME THE POWER IS TURNED OFF.

8. Push "COIN" to coin the game.
9. Push START 1 to start the game.
10. LLP moves the gun left and right.
 LRP moves the gun up and down.
 SL-5 fires the gun.
 START-2 is SLAM.