



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990


Operating Instructions

For Model

394A

BLUEPRINT

MIDWAY



1. Insert 394A program card into "A" connector on TF-650, number side up.
2. Plug 7 pin connector to J3 with the slots facing toward the board.
3. Plug 10 pin connector to J1 with the slots facing away from the board
4. Plug 20 pin connector to J2 with the slots facing away from the board
5. Connect speaker to short leads on J2.
6. Slide +5V to ON.
7. Slide POWER to ON.
8. CONTROLS ARE:

COIN-----COIN IN---LED should lite when pushed.

START 1----PLAYER 1 START

START 2----PLAYER 2 START

SR1-----MOVE LEFT

SR2-----MOVE UP

SR3-----MOVE RIGHT

SR4-----MOVE DOWN

SR5-----MOVE FAST

SL1-----LEFT)

SL2-----MOVE UP)

SL3-----MOVE RIGHT) COCKTAIL MODE

SL4-----MOVE DOWN)

SL5-----MOVE FAST 2 PLAYER)

SL6-----TILT

SL7-----RESET

MOVE SLIDE SWITCH TO TEST ON 394A card for self-test.

ROM SIGNATURES

<u>LOCATION</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>	<u>SIGNATURE</u>
1M	MBM 2732A-35	2732/M24	PF01
1N	"	"	4640
1P	"	"	2FCC
1R	"	"	63F2
1S	"	"	UP40
3U	"	"	33HH
3V	"	"	F397
C3	"	"	4UPF
D3	"	"	AU6H
D17	"	"	5H7U
D18	"	"	1762
D20	"	"	7F51