



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 337A---185B & 222C

24" Sound Cable

SPACE ENCOUNTERS/MIDWAY

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x					x	x	x			
x		SL4		x		x	x		SR4		x		
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 185B program card into "B" connector on TF-650 number side up.
2. Insert 337A program card into "A" connector on TF-650 number side up.
3. Insert 222C program card into 25-pin connector on TF-650 number side up.
4. Insert GAME MOTHER BOARD into 222C connector.
5. Connect 9-pin connector on 337A card to 9-pin header on GAME BOARD.
6. Connect 17-pin connector on 337A card to 17-pin header on GAME BOARD.
7. For SOUND, connect 12-pin connector on 337A card to 12-pin header on SOUND BOARD. Connect speaker across two RED leads.
8. Connect 23-pin connector of interconnect cable to 23-pin header on GAME BOARD. Connect 16-pin connector on the other end to SOUND BOARD 16-pin header.
9. Push 5 VOLT switch to ON.
10. Push POWER switch to ON.
11. COIN switch is COIN. LED on 337A card is COIN COUNTER.
12. SL5 FIRE button is also START button.
13. SR1 thru SR7 (except SR5) moves SPACE SHIP horizontally. Different combinations of switches controls movement of SPACE SHIP. All inputs to IC chips can be exercised.
14. SL1 thru SL7 (except SL5) moves SPACE SHIP vertically. Same as step 13.
15. START 2 is RESET.