



Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990


Operating Instructions

For Model

335A

ASTRO FIGHTER

DECO



1. Insert 335A program card into "A" connector on TF-650, with number side up.
2. Connect 10-pin .1" spacing connector from 335A card to Mother Board on game card cage with RED DOT toward PIN 1.
3. Connect 22 double readout connector to GAME BOARD with RED DOT towards PIN 1A.
4. Connect speaker across RED and BLACK leads on 335A program card. Potentiometer on 335A controls volume.
5. Slide 5 VOLT switch to ON.
6. Slide POWER switch to ON.
7. COIN is credit switch.
8. START 1 is 1 PLAYER
START 2 is 2 PLAYER
9. SR1 and SR3 control right-left movement for 1st player. SR5 is FIRE.
SL1 and SL3 control right-left movement for 2nd player.
SL5 is FIRE.
10. SR7 is SERVICE switch.
11. SR6 is RESET switch.