



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

291AD, 185B, 222C

SHUFFLEBOARD (291A) *

MIDWAY --

BOWLING ALLEY (291AD)*

		SL2				START 2			SR2				5V	
		x				x			x					
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP		ON	OFF
		x	x			x	x	x	x	x				
x		SL4		x	x	x	x		SR4		x			
		x							SR4					
	SL6		SL7			COIN		SR6		SR7			POWER	
	x		x			x		x		x	x			
													ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 291A card into program "A" connector, number side up.
3. Insert 222C card into 25 pin connector, number side up.
4. Insert Game Board into 222C card connector. (Care should be taken to line up traces on game board with connector pins.)
5. Connect 11 pin connector cable from 291A card to vertical control board, window side showing. On BOWLING ALLEY, use outside set of control board pins.
6. Connect 15 pin connector cable from 291A card to vertical control board, window side showing. On SHUFFLEBOARD, two unused pins will be toward outside of control board.
7. Connect 291D card to center set of control board pins.
8. Push COIN switch once for 1 credit.
9. START 2 is reset switch.

10. BOWLING ALLEY CONTROLS

START 1 is game select
Regulation or Flash
SR7 is START
SR6 is Hook or Straight

SHUFFLEBOARD CONTROLS

START 1 is game select
Game 1 or 2
SR6 is 1 player game
SR7 is 2 player game

11. SR2 is Ball Control vertical-----UP
12. SR4 is Ball Control vertical-----DOWN
13. SR1 is Ball Control horizontal---LEFT
14. SR3 is Ball Control horizontal---RIGHT