



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 403A
THE PIT
CENTURI

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 403A program card in slot "A" with number side up.
2. Connect the 22/44 edge connector to the board RED DOT UP.
3. Connect speaker to 6" leads.
4. Turn 5V to ON.
5. Turn POWER to ON.
6. CONTROLS ARE:

COIN----COIN-----CC Lights when pushed

START 1-----1 PLAYER

START 2-----2 PLAYER

SR1---MOVE LEFT

SR2---MOVE UP

SR3---MOVE RIGHT

SR4---MOVE DOWN

SR5---SHOOT

SL1---MOVE LEFT

SL2---MOVE UP

SL3---MOVE RIGHT

SL4---MOVE DOWN

SL5---SHOOT

UPRIGHT CONTROLS

PLAYER 2 COCKTAIL MODE

ROM SIGNATURESHT-01A BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
IC30	M5L2716K	3735	TI2716/I24
IC33	M5L2732K	F004	2732/M24
IC38	D2732	7U2P	"
IC39	"	HHPA	"
IC40	M5L2732K	8987	"
IC41	"	F4UP	"

HT-01B BOARD

IC8	M5L2716K	4UU7	2716/I24
IC9	"	U7A2	"