




**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246 • 2271 Arbor Blvd.  
 Dayton, Ohio 45439  
 Telephone (513) 299-0990

# Operating Instructions

For Model 306AB, 287C or 171C  
LUNAR LANDER  
ATARI



1. Insert 306B card into program "B" connector, number side up.
2. Insert 306A card into program "A" connector, number side up.
3. Connect speaker to RED and BLACK wires on 306A card.
4. Insert \*287C adapter card into 25-pin connector, number side up. (or 171C)
5. Insert GAME BOARD into \*287C card connector. (or 171C)

(NOTE)---X, Y Z outputs on GAME BOARD can be connected to X,Y, Z oscilloscope inputs. Some of the graphics can ben seen.

6. Push 5 VOLT switch to ON.
7. Push POWER switch to ON.
8. COIN 1 is 1st COIN.
9. START 1 is 2nd COIN.
10. SELECT/START LED is next to START 1.
11. SELECT is SR6. Attitude 0, 1, 2, 3 LED's are on 306A card.
12. START is SR7.
13. ROTATE RIGHT is SR3. ROTATE LEFT is SR1.
14. THRUST CONTROL is RLP potentiometer. Increase thrust is CLOCKWISE.
15. ABORT is SR5.
16. C is COIN COUNTER LED, on 306B card.
17. START 2 is TILT.