



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model

321A

STARFIRE-----EXIDY

		SL2				START 2			SR2				5V
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert the 321A card into the program A connector, number side up.
2. Connect a speaker to the speaker leads.
3. Connect the two outside cables from the corners of the 321A card to the two lower connectors of the game board.
4. Connect the center two cables to the upper three connectors of the game board.
5. Turn on +5 volts and AC power.
6. Push COIN to coin game.
7. Push START 1 to start game.
8. Turn: RLP for Velocity  
LRP for Horizontal  
LLP for Vertical
9. Push SR-6 for SLAM, SL-5 for FIRE.