




**Kurz-Kasch, Inc.**  
 Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-8161

# Operating Instructions

## For Model 288 AB, 265C

FIRE TRUCK, SMOKEY JOE  
ATARI



1. Insert the 288B card into program B connector, number side up.
2. Insert the 288A card into program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the game board into the 265C card.
5. Slide the POWER switch to ON.
6. Push COIN or START 1 to coin the game.
7. Push SR-6 for Track Select.
8. To start the game, PUSH:

|         |                  |
|---------|------------------|
| SL-2    | Front or START 1 |
| START-2 | Back or START 2  |
| SR-2    | Both or START 3  |

9.
 

|              |       |             |       |
|--------------|-------|-------------|-------|
| <u>FRONT</u> |       | <u>BACK</u> |       |
| SL-1         | Left  | SR-1        | Left  |
| SL-3         | Right | SR-3        | Right |
| SL-5         | Horn  | SR-5        | Bell  |
| SL-6         | Gas   |             |       |

10. Push SR-7 for Slam  
 Push SL-7 for Test