



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 365A
TURTLES
STERN

		SL2				START 2			SR2			5V	
		X				X			X				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	X	X	X		X	X	X	X	X	X			
		SL4							SR4				
		X							X				
	SL6		SL7			COIN		SR6		SR7		POWER	
	X		X			X		X		X	X	ON	OFF
												ON	OFF

1. Insert 365A program card into "A" connector on TF-650, number side up.
2. Connect 18 pin edge connector to the game board RED DOT UP.
3. Connect speaker to short leads on 18 pin connector for sound.
4. Slide 5V to ON.
5. Slide POWER to ON.
6. Controls are:

COIN is COIN 1
 SR 6 is COIN 2 (LED lights when either is pushed)

START 1 is PLAYER 1
 START 2 is PLAYER 2

SR1 - LEFT)
 SR2 - UP)
 SR3 - RIGHT) PLAYER 1
 SR4 - DOWN)
 SR5 - LAY EGG)

SL1 - LEFT)
 SL2 - UP)
 SL3 - RIGHT)
 SL4 - DOWN) PLAYER 2
 SL5 - LAY EGG)
 SL6 - SERVICE)

P.C.B.
KT4108-2

<u>MARKING</u>	<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
RA2 (41)	2C	2732	U620	2732 (M24)
RA2 (41)	2E	2732	62C4	2732 (M24)
RA2 (41)	2F	2732	06P5	2732 (M24)
RB1 (49)	2H	2732	UAHU	2732 (M24)
RA2 (41)	2J	2732	0316	2732 (M24)
RA2 (41)	5F	2716	72F2	2716 (I24)
RA2 (41)	5H	2716	C9C0	2716 (I24)

P.C.B.
KT4108-1

RB1 (21)	5C	2732	86A8	2732 (M24)
RB1 (21)	5D	2732	3494	2732 (M24)

9/27/82-----cw

PG. 2 OF 2