



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model 120 A

TV BASKETBALL

Midway

	SL2				START 2			SR2				5V	
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF	
	x	x	x		START 1		x	x	x				
x		SL4		x	x	x		SR4		x			
		x						x					
	SL6		SL7		COIN		SR6		SR7		POWER		
	x		x		x		x		x	x		ON	OFF

1. Insert 120 A card into program "A" connector, with number side up.
2. Insert computer board into test fixture using the 22 pin orientation.
3. Connect 10 pin connector to opposite end of computer board with the red dot up.
4. Turn power switch on.
5. Turn 5 volt internal switch on.
6. Push COIN switch once for 2 players, twice for 4 players.
7. Push START 1 switch once.
8. LLP is left paddle  
 RRP is right paddle  
 LRP is left right paddle  
 RLP is right left paddle
9. LED indicators on 120 A card are:  
 1 PLY is 1 player  
 2 PLY is 2 players  
 GO is game over