



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 417A
MILLIPEDE
ATARI

		SL2				START 2				SR2				5V
		x				x	x			x				
LLP	SL1	SL5	SL3	LRP				RLP	SR1	SR5	SR3	RRP	ON	OFF
		x	x			START1			x	x	x			
x					x	x	x	x		SR4		x		
		SL4												
		x								x				
	SL6		SL7			COIN			SR6		SR7		POWER	
	x		x			x			x		x	x	ON	OFF
													ON	OFF

1. Insert 417A card into slot A, number side up.
2. Connect 22/44 edge connector to board, RED DOT UP.
3. Connect 12/24 edge connector to board, RED DOT UP.
4. Connect the speaker to short leads on the 417A card.
5. CONTROLS ARE:
 - COIN---LEFT COIN----LED LIGHTS WHEN PUSHED
 - SR6----RIGHT COIN---LED LIGHTS WHEN PUSHED
 - SL7----AUX. COIN
 - START 1 -1 PLAYER----(LED'S IN TF-650 SHOW
 - START 2 -2 PLAYERS--- CREDITS FOR 1 or 2 PLAYERS)
 - SR1----MOVE LEFT
 - SR2----MOVE UP
 - SR3----MOVE RIGHT
 - SR4----MOVE DOWN
 - SR5----FIRE

TEST SWITCH IS ON 417A CARD.

AUDIO SWITCH FOR AUDIO 1 and AUDIO 2 IS ON 417A CARD.

7-PIN CONNECTOR IS FOR COLOR USE AND SYNC.

ROM SIGNATURES

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
1 H	TMS-2532-JL	C63C	TMS2532/L24M
1 J/K	"	CH74	"
1 L	HN462532G	F992	"
1 M/N	"	34FA	"
5 P	TMS-2516-JL	AU67	2716/I24
5 R	TMS-2516-JL	6CF6	"