



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

# Operating Instructions

For Model 360A  
ROLLING CRASH, MOON BASE  
GAMES, LTD/ NICHIBUTSU

		SL2			START 2			SR2			SW		
		X			X	X		X					
LLP	SL1	SL5	SL3	LAP		RLP	SR1	SRS	SR3	RRP	ON	OFF	
	X	X	X				X	X	X				
		SL4		X	X	X		SR4					
		X						X					
	SL6		SL7		COIN		SR6		SR7		POWER		
	X		X		X		X		X	X	ON	OFF	

1. Insert 360A program card into "A" connector on TF-650, with number side up.
2. Connect 18/36 pin cable connector on right hand side of 360A card to edgeboard connector on MB-3 (AUDIO BOARD) with dot facing up.
3. Connect 18/36 pin cable connector on left hand side of 360A card to edgeboard connector on MB-2 with dot facing up.
4. Connect 6-pin molex cable connector to mating connector on video output board.
5. Slide 5 volt switch to ON.
6. Slide POWER switch to ON.
7. GAME SELECT is on 360A card (RC or MB)
8. Controls are:  
 COIN is CREDIT  
 START 1 is 1 PLAYER  
 START 2 is 2 PLAYERS  
 SR1 is 1st player LEFT  
 SR2 is 1st PLAYER FIRE or SPEED  
 SR3 is 1st PLAYER RIGHT  
 SL1 is 2nd PLAYER LEFT  
 SL2 is 2nd PLAYER FIRE or SPEED  
 SL3 is 2nd PLAYER RIGHT

NOTE: When selecting MOON BASE GAME, jumper on MB-3 board between PIN R and U must be removed or 1st player movement will not work (LOCATED NEAR R16)

<u>LOCATION</u>	<u>MARKING</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
4A	RC-1	2708	73PA	2708 (H24)
4C	RC-2	2708	2P20	2708 (H24)
4E	RC-3	2708	5F80	2708 (H24)
4F-6	RC-4	2708	4480	2708 (H24)
4H	RC-5	2708	81P1	2708 (H24)
4L	RC-6	2708	6803	2708 (H24)
5A	RC-7	2708	AAHP	2708 (H24)
5C	RC-8	2708	3U50	2708 (H24)
5E	RC-9	TMS2516	C825	2716 (I24)
5F-6	RC-10	TMS2516	444H	2716 (I24)
5H	RC-11	TMS2516	4215	2716 (I24)
5L	CR-12	TMS2516	1344	2716 (I24)