




**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model OUTLAW  
198 A, B  
Atari



1. Insert 198 A card into program "A" connector, number side up.
2. Connect OUTLAW or QUAK gun to 198 B card, then insert card into program "B" connector, number side up.
3. Insert game board into 25 pin connector using 22 pin orientation.
4. Connect 8 ohm speaker to RED and BLACK wires on 198 B card.
5. Push COIN switch once, CDT (credit) LED will come on 198 B card.
6. Push START 1 switch once.
7. Push SR6 for MEDIUM DIFFICULTY, MD LED.  
 Push SR7 for HARD DIFFICULTY, HD LED.
8. GUN OPTICS LENS must be touching GUN LED for BAD GUY to come out after COIN and START.
9. SR5 is GUN TRIGGER. (POINT GUN AT BAD GUY)