



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990


## Operating Instructions

For Model

397A

JUNGLE HUNT

TAITO



1. Insert 397A into "A" slot in TF-650, number side up.
2. Connect 18/36 edge connector to "T" on lower board, RED DOT UP.
3. Connect 12-pin, 4 wire connector to "H" on TOP CARD.
4. Connect 22/44 edge connector to "G" on TOP CARD, RED DOT UP.
5. Turn 5V to ON.
6. Turn POWER ON.
7. Controls are: FOR JUNGLE HUNT, WHEN PUSHED....

COIN-----COIN LEFT-----BC LED SHOULD LITE

SR6-----COIN RIGHT-----TC LED SHOULD LITE

START 1--1 PLAYER

START 2--2 PLAYERS

SR1-----MOVE LEFT

SR2-----MOVE UP

SR3-----MOVE RIGHT

SR4-----MOVE DOWN

SR5-----JUMP/KNIFE

SL6-----SLAM/TILT

SL7-----SERVICE

SR7-----MASTER RESET

LL & RL LED's SHOULD GO OUT WHEN 9 CREDITS ARE ENTERED....

LOCATION                      TYPE                      SIGNATURE                      PERSONALITY BOARD

ROM BOARD

IC1	D2732D	2A48	2732/M24
IC2	"	9CPF	"
IC3	"	F0U7	"
IC4	"	H365	"
IC5	"	33UH	"
IC6	"	C0U4	"
IC7	M5L2732K	9723	"
IC8	D2732D	58P8	"

GAME BOARD

IC70	M5L2732K	UP87	2732/M24
IC71	"	29PH	"
IC72	"	5457	"

CPU BOARD

IC64	MBM2732A-30	U18F	2732/M24
IC65	"	2080	"
IC66	"	3574	"
IC67	"	2A03	"
IC68	"	0F24	"
IC69	D2732D	3H85	"
IC52	MBM2732A-30	888H	"
IC54	D2732D	1629	"
IC55	MBM2732A-30	2264	"