



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions For Model

SELECTOR UNIT
#601-08060

204A, C, D, E

193B
ROWE/AMI

| | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|---|---------|-----|-----|-----|-----|-----|----|-----|--------|
| | | SL2 | | | | START 2 | | | | SR2 | | | | 5V |
| | | x | | | | x | x | | | x | | | | |
| LLP | SL1 | SL5 | SL3 | LRP | | START 1 | RLP | SR1 | SR5 | SR3 | RRP | ON | OFF | |
| | x | x | x | x | x | x | x | x | x | x | x | | | |
| | | SL4 | | | | | | | SR4 | | | | | |
| | | x | | | | | | | x | | | | | |
| | SL6 | | SL7 | | | COIN | | SR6 | | SR7 | | | | POWER |
| | x | | | | | x | | x | | x | x | | | ON OFF |

1. Insert 193B card into program "B" connector, number side up.
2. Insert 204A card into program "A" connector, number side up.
3. Insert 204C card into 25 pin connector with number side up.
4. Connect cables from 204C card to SELECTOR UNIT 601-08060 connectors P502, P503, P506.
5. Connect 204D card to SELECTOR UNIT connector P505.
6. Connect 204E card to SELECTOR UNIT connector P501.
7. Push 5 VOLT switch to ON.
8. Push POWER switch to ON.
9. SELECTION numbers are:

SL1 - 1
SL2 - 2
SL3 - 3
SL4 - 4
SL5 - 5

SR1 - 6
SR2 - 7
SR3 - 8
SR4 - 9
SR5 - 0

START 2 is RESET

10. Select a number between 100 and 299. It will display on 204A card and on the 204E card. Also the SC (STANDARD CANCEL) or PC (PREMIUM CANCEL) 204A card LED will indicate whether record selected used premium or standard selection. YS (YOUR SELECTION) will indicate on 204D card.
NOTE: If the first number selected is other than a 1 or 2 the RR (RESET and RESELECT) LED will blink on the 204D card. Push RESET (START 2) to clear.

11. To check SELECTOR UNIT acknowledgement pick a fault number to make RR LED blink. Push RESET (START 2) to clear. Now hold down SL7, RNP (RECORD NOW PLAYING) will come on along with the number 200 displayed on 204E card.