



Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990


Operating Instructions

For Model

377A

DONKEY KONG

NINTENDO



1. Insert 377A program card into "A" connector on TF-650 with number side up.
2. Connect 10-pin ribbon cable connector to VIDEO BOARD with RED DOT to pin 1 of P3.
3. Connect 9, 5, 4, 12, 17, 2 and 3 pin ribbon cable connectors to P9, P8, P10, P6, P5, P4 and P3 respectively on CPU BOARD. Also connect 6-pin ribbon cable RED connector to P7.
4. Connect speaker across short RED and BLACK leads on 377A card. AUDIO level control is on 377A card.
5. Slide 5 VOLT switch to ON.
6. Slide POWER switch to ON.
7. Controls are:
 - COIN is CREDIT (coin counter LED is on 377A card.)
 - START 1 is 1 PLAYER START
 - START 2 is 2 PLAYER START
 - SR1 is LEFT
 - SR3 is RIGHT
 - SR2 is UP
 - SR4 is DOWN
 - SR5 is JUMP
8. TEST switch is on 377A card (if used)
9. SR7 is SERVICE SWITCH.

MPU BOARD

<u>MARKING</u>	<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
TKG4-C	3F	2716	H656	2716/I24
TKG4-C	3H	2716	65A4	2716/I24
TKG4-C	5A	TMS2532	F4P1	TMS2532/L24M
TKG4-C	5B	TMS2532	8276	TMS2532/L24M
TKG4-C	5C	TMS2532	P9C8	TMS2532/L24M
TKG4-C	5E	TMS2532	9C74	TMS2532/L24M

VIDEO BOARD

TKG4-V	3N	2716	2931	2716/I24
TKG4-U	3P	2716	U735	2716/I24
TKG4-V	7C	2716	1AUP	2716/I24
TKG4-V	7D	2716	2C00	2716/I24
TKG4-V	7E	2716	732C	2716/I24
TKG4-V	7F	2716	A1A5	2716/I24