



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model

424A

CONGO BONGO

SEGA

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x					x	x	x			
x		SL4		x	x	x	x		SR4		x		
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x		
												ON	OFF

1. Insert 424A into slot "A" of TF-650, number side up.
2. Connect 22/44 edge connector to the game board, RED DOT UP.
3. The short leads on the edge connector connect to the speaker.
4. Turn 5V and power to ON.
5. Controls are:

COIN-----COIN A {c.c. A and c.c. B should light when pushed}  
 SR6-----COIN B  
 SL7-----SERVICE  
 START 1-----1 PLAYER  
 START 2-----2 PLAYERS  
 SL6-----RESET  
 SR1-----LEFT  
 SR2-----UP  
 SR3-----RIGHT  
 SR4-----DOWN  
 SR5-----JUMP  
 SL1-----LEFT )  
 SL2-----UP )  
 SL3-----RIGHT ) PLAYER 2 COCKTAIL VERSION  
 SL4-----DOWN )  
 SL5-----JUMP )

Test switch is on game board.  
7-pin right angle connector is to allow video and sync hook up to color.

ROM SIGNATURES

TOP BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
U21	TMS2764JL-25	2C44	Intel 2764
U22	"	1Ø1U	"
U23	"	6U52	"
U24	"	57CF	"
U19	"	P633	"
U77	"	ØC1H	"

BOTTOM BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
U57	TMS2764JL-25	615F	Intel 2764
U58	"	9557	"
U77	"	1F95	"
U78	"	UU48	"
U79	"	4H67	"
U93	"	PF15	"
U94	"	18F4	"
U95	"	6668	"
U104	"	2P95	"
U105	"	CUF5	"
U106	"	96UØ	"