



Kurz-Kasch, Inc.

2271 Arbor Boulevard
P.O. Box 1246
Dayton, Ohio 45401
Tel- (513)299-0990

Operating Instructions

For Model 253A, 185B, 222C

BOOT HILL

Midway

	SL2			START 2			SR2		5 V			
LLP	SL1	x	SL3	LRP	x	x	SR1	x	SR3	RRP	ON	OFF
		SL5			START 1		SR5					
x		x	x	x	x	x	x	x	x	x		
		SL4					SR4					
	SL6	x	SL7	COIN			SR6	x	SR7		POWER	
	x		x	x			x		x	x	ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 253A card into program "A" connector, number side up.
3. Insert 222C card into test fixture, number side up.
4. Insert Boot Hill game board into 222C connector.
5. Connect 24 pin and 13 pin Molex connectors to game board, with orange dot toward component side.
6. Connect speakers to speaker leads. Do not ground speaker or speaker leads.
7. Slide 5 VOLT switch to ON.
8. Slide POWER switch to ON.
9. Push COIN to coin game.
10. Select 1 Player or 2 Player with the momentary switch on the 253A card. START 2 is reset.

11.	LEFT MAN	RIGHT MAN
	SL-1	LEFT
	SL-3	RIGHT
	SL-2	UP
	SL-4	DOWN
	SL-5	TRIGGER
	SL-6	GUN
	SL-7	GUN
		SR-1
		SR-3
		SR-2
		SR-4
		SR-5
		SR-6
		SR-7

NOTE: Left gun will point up and right gun will be straight. All three inputs will be activated with switches 6 & 7.