




Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model 248 A C

BARRICADE

Ramtek



1. Insert 248C card into TEST FIXTURE connector, number side up.
2. Insert 248A card into Program "A" connector, number side up.
3. Insert GAME BOARD into 248C Card cinch connector.
4. Connect 8 OHM speaker to RED and BLACK wire on 248B card.
5. Push 5 VOLT switch to ON.
6. Push POWER switch to ON.
7. Push COIN once for 2 players, twice for 4 players.
8. Push START 1 once.
9. SWITCH on 248C card selects players 1 and 2 or 3 and 4 controls which are:

1 OR 2

- SR1 - LEFT
- SR2 - UP
- SR3 - RIGHT
- SR4 - DOWN

2 OR 4

- SL1 - LEFT
- SL2 - UP
- SL3 - RIGHT
- SL4 - DOWN