



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model 192A, 185B, C

SEAWOLF

Midway

		SL2			START 2		SR2		5V			
		x			x	x	x					
LLP	SL1	SL5	SL3	LRP	START 1	ALP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x		
		SL4						SR4				
	SL6	x	SL7		COIN		SR6	x	SR7		POWER	
	x		x		x		x		x	x	ON	OFF

1. Insert 192A card into program "A" connector, number side up.
2. Insert 185B card into program "B" connector, number side up.
3. Insert 185C extender card into test fixture, number side up.
4. Insert computer board into 185C extender card.
5. Connect 12 pin and 22 pin molex edgeboard connectors to vertical computer board with orange dot facing on component side.
6. Connect rectangular 12 pin AMP connector to sound board. (Game will operate without sound board.) Connect a speaker across two RED wires.
7. Push 5 VOLT switch to ON.
8. Push POWER switch to ON.
9. Push START 2 once for COMPUTER RESET.
10. Push COIN once.
11. Push START 1 once.
12. SR1 thru SR5 will exercise all opto-isolator inputs which control torpedo firing locations. Any combinations of SR1 thru SR5 will give different firing locations.
13. To fire torpedos, SR1 thru SR5 must be held down before pushing firing switch SR6.
14. To ERASE high score push SR7.