



Kurz-Kasch, Inc. KURZ-KASCH INC.

Electronics Division
Box 1246

Dayton, Ohio 45401

ELECTRONICS DIVISION
2271 ARBOR BLVD.

DAYTON, OHIO 45439


Operating Instructions

For Model

307A, 185B, 222C

BLUE SHARK

MIDWAY



1. Insert 185B program card into TF-650 "B" connector.
2. Insert 307A program card into TF-650 "A" connector.
3. Insert 222C card into 25-pin connector.
4. Insert Game Board into 222C card connector.
5. Connect 8 pin and 11 pin connector on 307A to Game Board.
6. Connect speaker across 2 red wires on 307A card connector.
7. Push 5 volt switch to ON.
8. Push POWER switch to ON.
9. RESET switch is Start 2.
10. COIN switch is COIN.
11. SL5 is TRIGGER switch.
12. LLP is SPEAR GUN position.