



Kur?Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990


Operating Instructions

For Model

420A

STAR TREK

SEGA



1. Insert 420A card into slot A, number side up.
2. Remove the top from the metal cage, which contains the circuit boards.
3. Starting with the 5 wires connected to "2" 4-pin MOLEX connectors, connect the 4-pin MOLEX with 3 wires to the X-Y control board with the slots toward the board. Connect the 4-pin MOLEX with 2 wires to the X-Y timing board with the slots toward the board.
4. Starting with the 18 wires connected to a 4, 6, 12 & 20 pin MOLEX, connect the 6-pin MOLEX to the "SPEECH" board with the SLOTS TOWARD THE BOARD. Connect the 4-pin MOLEX to the "SOUND" board with the SLOTS AWAY FROM THE BOARD. Connect the 20-pin MOLEX to the side nearest the test push button, SLOTS SHOULD BE AWAY FROM THE "CPU" BOARD. Leave the 20 pins on the left side of the CPU board connected to J1. Connect the 12-pin connector to the "INTERFACE" board-- (800-0374), and connect J1 to the interface board.
5. Starting with the 8 wires connected to a 10-pin MOLEX, connect to the bottom connector on the cage with the slots up.
6. Hook speaker to short red and black wires.
7. Turn 5V and POWER to ON position.
8. Controls are:
 - SL7-----SERVICE
 - COIN-----LEFT COIN
 - SR6-----RIGHT COIN
 - START 1-1 PLAYER
 - START 2-2 PLAYERS
 - SR1-----TURN LEFT
 - SR2-----IMPULSE
 - SR3-----TURN RIGHT
 - SR7-----WARP
 - SR7-----PHOTON (after WARP is used up)
9. A 7-pin right angle connector is on the card fox access to X, Y, RED, GREEN, BLUE, AND GROUND....

POSITIONTYPESIGNATUREPERSONALITY BOARDX-Y TIMING

U39

2708

P8C2

2708/H24

PROM BOARD

U1

D2716-5

51F4

2716

U2

"

9A24

"

U3

"

A8HP

"

U4

"

F099

"

U5

"

FA30

"

U6

"

U9H3

"

U7

"

247U

"

U8

"

779C

"

U9

"

U64A

"

U10

"

F373

"

U11

"

1AA2

"

U12

"

PH1A

"

U13

"

CP63

"

U14

"

58FC

"

U15

"

7716

"

U16

"

5PU3

"

U17

"

P444

"

U18

"

F070

"

U19

"

C13H

"

U20

"

494U

"

U21

"

9AU2

"

U22

"

334U

"

U23

"

A5U2

"

SPEECH BOARD

U5

D2732-D

H558

2732/M24

U6

"

2PA7

"

U7

D2716-5

9673

"

CPU BOARD

U25

D2716-5

864C

2732/M24