



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990


# Operating Instructions

For Model

423A

BUCK ROGERS

SEGA



1. Insert 423A program card into "A" connector on TF-650, number side up.
2. Insert GAME BOARD into 44-pin edge connector with RED DOT facing up at pin 1.
3. Connect 4-pin ribbon cable connector to "A" header pins on SOUND BOARD.
4. Connect speaker across "B" header pins on sound board.
5. Slide 5 VOLT switch to ON.
6. Slide POWER switch to ON.
7. Controls are:

COIN is-----COIN 1 (coin counter LED is on 423A card) [CC]

SL7 is-----COIN 2 (coin counter LED is on 423A card) [CC]

START 1 is-----1 PLAYER

START 2 is-----2 PLAYER

SR1 is-----LEFT

SR2 is-----UP

SR3 is-----RIGHT

SR4 is-----DOWN

SR5 is-----FIRE

SR6 is-----DOWN SPEED

SR7 is-----UP SPEED

8. SL6 is SERVICE SWITCH

9. SL4 is SELF TEST SWITCH

CPU BOARD

<u>POSITION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
1C3	D27128-3	2UH7	Intel 2764
1C4	"	A4U7	"
1C10	TBP28S46N	PH8H	6341/E24
1C39	TBP18S030N	00PC	82S123/D16
1C53	"	4F6C	"
1C66	D2732A-2	PC19	2732/M24
1C78	TBP28S46N	376F	6341/E24
1C91	MBM2764		
1C93	TBP28S46N	3U29	6341/E24
1C102	2716D	U88H	2716/I24
1C103	462716G	U418	"

ROM BOARD

1C43	D27128-3	24A8	Intel 2764
1C52	"	AH55	"
1C58	MBM2764-30	8PA4	"
1C59	D27128-3	6PC1	"
1C68	"	C20P	"
1C74	MBM2764-30	80FF	"
1C75	D27128-3	9HF0	"
1C84	MBM2764-30	FF48	"
1C90	"	CFU7	"
1C91	D27128-3	25UF	"
1C100	MBM2764-30	8103	"