




# Kurz-Kasch, Inc.

Electronics Division  
Box 1246  
2876 Culver Ave.  
Dayton, Ohio 45401  
Telephone (513) 296-0330

## Operating Instructions For Model 137 A

TV Pin Game

C D I



1. Insert 137 A Card into program "A" connector with number side up.
2. Insert 137 C extender card into 25 pin connector with number side up.
3. Connect 6 pin connector from 137 A card to computer board with red dot up.
4. Insert computer board into 137 C extender card.
5. Turn power switch on.
6. Turn 5 volt internal switch on.
7. Push coin once for 1 player, twice for two players.
8. SR 6 is serve ball,  
RRP is paddle control.
9. "G" LED'S on 137 A card checks gong circuit  
"1P" and "2P" is switch for one player or 2 player on 137 A card.