




Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990

Operating Instructions

For Model 378AB
QIX
TAITO



1. Insert 378B program card into "B" connector on TF-650, with number side up.
2. Connect longest ribbon cable connector leaving 378B card to J1 header on video board.
3. Connect remaining two ribbon cable connectors leaving 378B card to ROM I/O board J11 header pins and DATA/SOUND J1 header pins.
4. Insert 378A program card into "A" connector on TF-650, with number side up.
5. Connect longest ribbon cable connector leaving 378A card to J2 header pins on VIDEO BOARD.
6. Connect remaining two ribbon cable connectors leaving 378A program card to RAM I/O board header pins J15 and J16.
7. Connect a speaker across J7 pins 1 and 2, also pins 3 and 4.
8. Slide 5 volt switch to ON.
9. Slide POWER switch to ON.
10. Controls are:

SL7 is LEFT COIN SW
 COIN is RIGHT COIN SW
 START 1 is 1 PLAYER
 START 2 is 2 PLAYER
 SR6 is SLOW DRAW
 SR7 is FAST DRAW
 SR1 is LEFT)
 SR2 is UP)
 SR3 is RIGHT)
 SR4 is DOWN)

→ Slow or fast draw button must be activated before pushing UP, DOWN, LEFT and RIGHT MOVEMENT.

11. Advance test is SL3
 Sub test is SL1
 Slow up is SL2
 Slow down is SL4

12. Tilt is SL6

ROM SIGNATURES

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>
U4	QQ4-02	0451	AM2716	2716/I24
U5	QQ5-02	A4P1	"	"
U6	QQ6-02	10C5	"	"
U7	QQ7-02	04HA	"	"
U8	QQ8-02	CCC4	"	"
U9	QQ9-02	957U	"	"
U10	QQ10-02	A407	"	"
U12	QQ12-02	965U	"	"
U13	QQ13-02	A4AP	"	"
U14	QQ14-02	1878	"	"
U15	QQ15-02	2444	"	"
U16	QQ16-02	2C9P	"	"
U17	QQ17-02	HU37	"	"
U18	QQ18-02	80AA	"	"
U19	QQ19-02	4180	"	"
U27	QQ27-02	C4HC	"	"