



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model 402A

TIME PILOT/LOCO-MOTION

CENTURI

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x					x	x	x			
x		SL4		x	x	x	x		SR4		x		
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x		
												ON	OFF

1. Insert 402A program card in slot "A" with number side up.
2. Connect the 18/36 edge connector to the board, RED DOT UP.
3. Connect speaker to 6" leads.
4. Turn 5V to ON.
5. Turn POWER ON.
6. Controls are:

COIN---COIN 1---CC1 lights when pushed  
 SR6----COIN 2---CC2 lights when pushed  
 START 1-----1 PLAYER ----- /  
 START 2-----2 PLAYER /  
 SR1---MOVE LEFT / Upright  
 SR2---MOVE UP / Mode  
 SR3---MOVE RIGHT / 1 & 2  
 SR4---MOVE DOWN /  
 SR5---SPEED (Loco-Motion)/Fire (Time Pilot) /  
 SL1---MOVE LEFT /  
 SL2---MOVE UP / PLAYER  
 SL3---MOVE RIGHT / 2  
 SL4---MOVE DOWN / COCKTAIL  
 SL5---SPEED (Loco-Motion)/Fire (Time Pilot) / MODE  
 SL7---SERVICE

ROM SIGNATURESLOCO-MOTIONSOUND BOARD

<u>POSITION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
-----------------	-------------	------------------	--------------------------

B1	M5L2732K	C66U	2732/M24
----	----------	------	----------

CPU BOARD

R1	M5L2732K	658A	2732/M24
----	----------	------	----------

R2	"	82P4	"
----	---	------	---

R3	"	7097	"
----	---	------	---

R4	"	CF5A	"
----	---	------	---

R5	"	AF5A	"
----	---	------	---

R9	"	4F2P	"
----	---	------	---

R10	"	37HU	"
-----	---	------	---

TIME PILOTSOUND BOARD

A7	M512732K	3F16	2732/M24
----	----------	------	----------

CPU BOARD

C10	MBM2764-30	02H1	Intel 2764
-----	------------	------	------------

C11	"	4947	"
-----	---	------	---

F11	"	A577	"
-----	---	------	---

H2	"	4U26	"
----	---	------	---

H3	"	F9P9	"
----	---	------	---

H4	"	8AA7	"
----	---	------	---