



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions For Model 176 A, B

WORLD CUP/GOAL IV

|     |     |     |     |     |   |         |     |     |     |     |     |       |     |    |
|-----|-----|-----|-----|-----|---|---------|-----|-----|-----|-----|-----|-------|-----|----|
|     |     | SL2 |     |     |   | START 2 |     |     |     | SR2 |     |       |     | 5V |
|     |     | x   |     |     |   | x       | x   |     |     | x   |     |       |     |    |
| LLP | SL1 | SL5 | SL3 | LRP |   | START 1 | RLP | SR1 | SR5 | SR3 | RRP | ON    | OFF |    |
| x   | x   | x   | x   | x   | x | x       | x   | x   | x   | x   | x   |       |     |    |
|     |     | SL4 |     |     |   |         |     |     | SR4 |     |     |       |     |    |
|     |     | x   |     |     |   |         |     |     | x   |     |     |       |     |    |
|     | SL6 |     | SL7 |     |   | COIN    |     | SR6 |     | SR7 |     | POWER |     |    |
|     | x   |     | x   |     |   | x       |     | x   |     | x   | x   | ON    | OFF |    |

1. Insert 176 A card into program "A" connector, with number side up.
2. Insert 176 B card into program "B" connector, number side up.
3. Insert computer board into test fixture using 22 pin orientation.
4. Push power switch to ON.
5. Select 1 or 2 player with switch on program card 176 A.
6. Push COIN switch once for 1 player, twice for 2 player.  
Credit LED will illuminate next to START 1 switch.
7. Push START 1 switch once.
8. RRP is defense paddle (checks)  
 RLP is offense paddle (checks)  
 LLP is defense paddles (solids)  
 LRR is offense paddles (solids)  
 SR 5 is kick (checks)  
 SL 5 is kick (solids)