



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 209 A, B

HIT ME

Ramtek



1. Insert 209 A card into program "A" connector, number side up.
2. Insert 209 B card into program "B" connector, number side up.
3. Connect 8 OHM speaker across RED and BLACK leads on 209B card.
4. Insert game board to be tested into test fixture using 15 pin orientation.
5. Push 5 VOLT switch to ON.
6. Push POWER switch to ON
7. Push COIN switch once.
8. Push START 1 switch once.

9. <u>1st. Player</u>	<u>2nd Player</u>	<u>3rd Player</u>	<u>4th Player</u>
SL1 - ANTE	SL6 - ANTE	SR1 - ANTE	SR6-ANTE
SL2 - HIT	SL4 - HIT	SR2 - HIT	SR4 - HIT
SL3 - STAND	SL7 - STAND	SR3 - STAND	SR7 - STAND

10. Start 2 is TILT switch.