



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 219 A, B

LEMANS

ATARI

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LAP		START 1	ALP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x	x	x	x	x	x	x	x	x		
x		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 219 A card into program "A" connector, number side up.
2. Insert 219 B card into program "B" connector, number side up.
3. Insert game board into test fixture using 22 pin orientation.
4. Connect speaker across RED and BLACK leads on 219 A card.
5. Push POWER switch to ON.
6. Push COIN switch once, ST (credit LED) will light on 219 B card.
7. Push START 1 switch once.
8. SR6 is GAS
 SR1 is 1st GEAR
 SR2 is 2nd GEAR
 SR3 is 3rd GEAR
 SR4 is 4th GEAR
 SR7 is BRAKE
9. SR5 is STEERING RIGHT
 SL5 is STEERING LEFT
10. EXT (extended play) LED is on 219 B card.