



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

# Operating Instructions

For Model

405A

FRONT LINE

TAITO

	SL2				START 2			SR2		5V		
	x				x	x		x				
LLP	SL1	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x			x	x	x	x	x			
x		SL4		x	x	x		SR4		x		
		x						x				
	SL6		SL7		COIN		SR6		SR7		POWER	
	x		x		x		x		x	x		
											ON	OFF

1. Insert 405A program card in slot "A" number side up.
2. Connect 22/44 edge connector to board, RED DOT UP.
3. Connect 18/36 edge connector to board, RED DOT UP.
4. Connect 12 pin MOLEX to board.
5. Turn 5V, and power to on position.
6. Connect speaker to 6" leads.
7. Controls are:

COIN----COIN 1----BC LED SHOULD LITE WHEN PUSHED

SR6-----COIN 2----TC LED SHOULD LITE WHEN PUSHED

START 1-----1 PLAYER

START 2-----2 PLAYER

SL7-----SERVICE SWITCH

SR1-----MOVE LEFT

SR2-----MOVE UP

SR3-----MOVE RIGHT

SR4-----MOVE DOWN

SR5-----FIRE

SL1-----AIM GUN LEFT

SL2-----AIM GUN UP

SL3-----AIM GUN RIGHT

SL4-----AIM GUN DOWN

SL5-----THROW GRENADE/JUMP

SL6-----TILT

SR7-----RESET

LL & RL LED'S GO OUT WHEN 9 CREDITS ARE ENTERED
--