



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions For Model 108 A

DUAL - KNOCKOUT

Digital Games

		SL2				START 2			SR2				5V
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x			x		x	x	x			
x		SL4		x		x	x		SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7			POWER
	x		x			x		x		x	x		
												ON	OFF

1. Insert program card with number facing you in slots A or B, as marked.
2. Power on
3. Coin (once for 2 players - twice for 4 players)
4. Start 1
5. LLP - left-left paddle control
6. LRP - left-right paddle control
7. RLP - right-left paddle control
8. RRP - right-right paddle control
9. Switch 1 on program card is for game selection.