



Kurz-Kasch, Inc.


Electronics Division
Box 1246
1501 Webster Street
Dayton, Ohio 45401
Telephone (513) 223-8161

Operating Instructions

For Model 292A, 185B, 222C

DOG PATCH

MIDWAY



1. Insert the 185B card into the program B connector, number side up.
2. Insert the 292A card into the program A connector, number side up.
3. Insert the 222C card into the test fixture, number side up.
4. Insert the Dog Patch mother board into the 222C card,
5. Connect the 2 Molex connectors to the top of the game board.
6. Connect 2 speakers to the speaker leads.
7. Slide the 5V switch to ON.
8. Slide the Power switch to ON.
9. Push the Coin switch to coin game.
10. Start the game with the switch on the 292A card.
11.

<u>Left Player</u>		<u>Right Player</u>
SL-1, SL-2, SL-3	AIM	SR-1, SR-2, SR-3
SL-5	FIRE	SR-5
12. Push START 2 for Reset.