



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Cuiver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model _____

187 A & 187 B

FIREPOWER

ALLIED

	SL2				START 2				SR2			5V	
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	SR5	SR3	RRP	ON	OFF
		SL5			START 1			x	x	x			
x	x	x	x	x	x	x	x		SR4		x		
		SL4											
	SL6	x	SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x	ON	OFF

1. Insert 187 A card into program "A" connector, number side up.
2. Insert 187 B card into program "B" connector, number side up.
3. Insert audio module into 18 pin remote connector with red dot facing up.
4. Insert computer board into test fixture.
5. Connect speaker across red leads on 18 pin remote connector. (DO NOT CONNECT SPEAKER TO GND).
6. Push power switch to on.
7. Push 5 volt internal switch to on.
8. Push COIN switch once.
9. Push START 1 switch once.
10. Speed control is SR6, SLOW & FAST conditions for test purposes only. (Game has variable speed control).
11. Gun button is SR5
12. Tank movement (DRIFT) is RRP. Left (L) and right (R) trimmer adjustments are on 187 A program card.