



Kurz-Kasch, Inc.

Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990

Operating Instructions

For Model 400A

BURGER TIME

MIDWAY

		SL2				START 2			SR2				5V
		x				x			x				
LLP	SL1	SL5	SL3	LAP		START1	ALP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x			x	x	x	x	x			
		SL4		x	x	x	x		SR4		x		
		x							x				
	SL8		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 400A program card into "A" connector on TF-650.
2. Connect the 10/20 connector to game board, observe the key for proper alignment.
3. Connect the 18/36 connector to game board, observe the key for proper alignment.
4. Connect speaker to the two 6" wires.
5. Turn 5V to ON.
6. Turn POWER to ON.
7. Controls are:

COIN----Coin 1 & 2 = = = LED SHOULD LITE WHEN PUSHED...

SR6-----SERVICE SWITCH

SR1-----MOVE LEFT

SR2-----MOVE UP

SR3-----MOVE RIGHT

UPRIGHT

SR4-----MOVE DOWN

SR5-----PEPPER

Test 1 & 2 are on program card.

SL7-----TILT

SL1-----MOVE LEFT

SL2-----MOVE UP

SL3-----MOVE RIGHT

#2 COCKTAIL VERSION

SL4-----DOWN

SL5-----PEPPER

SOUND BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
1B	TMM2716	H305	2716
3B	"	857P	"
4B	MB8516	6U4P	"
6B	AM2716DC	9PHP	"
9B	MBM2732A-35	UF19	2732/M24
10B	"	5A53	"
12B	D2732A-3	4CA3	"
13B	"	0C9F	"
15B	MBM2732A-35	9FFP	"
12H	D2732A-3		

CPU BOARD

7K	MBM2732A-35	3657	2732/M24
9K	M5L2732K	8449	"
10K	"	4334	"
12K	"	05P8	"
13K	MBM2732A-35	U94A	"
15K	M5L2732K	P666	"

ALL ROMS ARE AB??--1 SERIES