



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions For Model

235A (185B & 222C)

MAZE

Midway

		SL2				START 2			SR2			5V	
LLP		x				x			x				
	SL1	SL5	SL3	LRP			RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x			START 1		x	x	x			
		SL4		x		x	x	x	SR4		x		
		x							x				
	SL6		SR7			COIN		SR6		SR7		POWER	
	x					x		x		x	x		
												ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 235A card into program "A" connector, number side up.
3. Insert 222C card into test fixture with number side up.
4. Insert game mother board into test fixture using 18 pin orientation.
CAUTION: Make sure edgeboard pin alignment is correct.
5. Connect two remote connectors from 235A card to game control board with red dot showing.
6. Push 5 VOLT switch to ON.
7. Push POWER switch to ON.
8. Push COIN switch once.
9. Push SR5 for RIGHT PLAYER START. Push SL5 for LEFT PLAYER START.

10. RIGHT PLAYER CONTROLS

- SR1 - OBJECT LEFT
- SR2 - OBJECT UP
- SR3 - OBJECT RIGHT
- SR4 - OBJECT DOWN

LEFT PLAYER CONTROLS

- SL1 - OBJECT LEFT
- SL2 - OBJECT UP
- SL3 - OBJECT RIGHT
- SL4 - OBJECT DOWN