



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

422A

MAD PLANETS

MYLSTAR (Gottlieb)

		SL2				START 2			SR2				5V	
		x				x			x					
LLP	SL1	SL5	SL3	LRP		START1	R.P.	SR1	SR5	SR3	RRP	ON	OFF	
x	x	x	x	x	x	x	x	x	x	x	x			
		SL4							SR4					
		x							x					
	SL6		SL7			COIN		SR6		SR7			POWER	
	x		x			x		x		x	x		ON	OFF

1. Insert 422A program card into "A" connector on TF-650, number side up.
2. Connect GAME BOARD to ribbon cable to 60-pin connector with RED DOT up.
3. Connect 14-pin connector to interface board.
4. Slide 5 VOLT switch to ON.
5. Slide POWER switch to ON.
6. Controls are:
 - COIN is COIN 1 (coin counter LED is on 422A card)
 - SL7 is COIN 2
 - 1 PLAYER is START 1
 - 2 PLAYER is START 2
 - SR1 is LEFT
 - SR2 is UP
 - SR3 is RIGHT
 - SR4 is DOWN
 - SR5 is FIRE
 - SR6 is ROTATE LEFT
 - SR7 is ROTATE RIGHT
7. TEST switch is on 422A card (P-PLAY, T-TEST)
8. TEST step switch is SL6.

MAIN BOARD

<u>POSITION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
C11-12	D2764	6F28	Intel 2764
C12-13	"	5679	"
C13-14	"	F483	"
C14-15	"	890P	"
C16	"	6AFC	"
E11-12	D2732-3	F180	2732/M24
E13	"	4A66	"
K4	"	F2PA	Intel 2764
K5	"	3P1U	"
K6	"	4955	"
K7-8	"	994P	"