



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions

For Model 185 A. B. C

GUN FIGHTER

Midway

		SL2				START 2			SR2				5 V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x		x	x	x	x	x	x			
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 185 A card into program "A" connector, number side up.
 2. Insert 185 B card into program "B" connector, number side up.
 3. Insert 185 C card into test fixture with number side up.
 4. Insert computer board into 185 C card connector.
 5. Connect a speaker to each red wire and black wire (common ground) on 185 A program card.
 6. Push POWER switch to ON.
 7. Push 5 VOLT switch to ON.
 8. Push COIN switch once.
 9. Push START 1 switch once.
 10. Start 2 switch is TILT.
- | | | | |
|----------|-------------------|------|--------------------|
| 11. SL 1 | Left man left | SR 1 | Right man left |
| SL 2 | Left man up | SR 2 | Right man up |
| SL 3 | Left man right | SR 3 | Right man right |
| SL 4 | Left man down | SR 4 | Right man down |
| SL 5 | Gun Trigger | SR 5 | Gun Trigger |
| SL 6 | Left man arm down | SR 6 | Right man arm down |
| SL 7 | Left man arm up | SR 7 | Right man arm up |

185 GUNFIGHTER GUN & BULLET SYNC

RIGHT GUN - Connect to ground pins 11 and 15, on vertical mounted control board, then push SR6. Right gun and bullet will be in sync.

LEFT GUN - Connect to ground pins 12 and 16, on vertical mounted control board, then push SL6. Left gun and bullet will be in sync.