



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990


## Operating Instructions

For Model

391AB/171C

FROGGER

GREMLIN/SEGA



### "EDGE CONNECTOR STYLE"

1. Insert "A" card in "A" slot of TF-650, number side up.
2. Insert "B" card in "B" slot on TF-650, number side up.
3. Insert "171C" in "C" slot on TF-650, number side up.
4. Insert MAIN BOARD 22 pin edge contacts into "171C" card.
5. Slide 5V to ON.
6. Slide POWER to ON.
7. Controls are:

COIN-----COIN (LED SHOULD FLASH WHEN PUSHED)

START 1----1 PLAYER START

START 2----2 PLAYER START

SR7-----SERVICE SWITCH

SL7-----RESET

SR1-----LEFT

SR2-----UP

SR3-----RIGHT

SR4-----DOWN

5K pot. on "A" board is volume control.

short leads on "B" card are speaker leads.